

# ANTICEPTIC MOISTURISING CREAM RAW MATERIAL + PACKAGING PACK

**Cost ₹2000/- To Make 2.5kg & 100 Container of 25gm**

**(25GM ANTICEPTIC MOISTURISING CREAM COST @20/- RS)**

**(Shipping Extra (parcel gross weight - approx 5kg))**

## IN THIS PACK YOU WILL GET :-

- 1kg - Mineral oil
- 200gm - P. Wax
- 100gm - M. Wax
- 125gm - E. Wax
- 15gm - Boric Acid
- 5gm - Preservative
- 175gm - Glycerince
- 25gm - Borobliss Perfume
- 2gm Container - 100 Pcs
- 875gm - R.O. Water Required

## 2.5kg Antiseptic Moisturizing Cream How to Make:

**STEP 1 - First, prepare the Water Phase in a stainless steel container. Add: 175 gm - Glycerin, 875 gm - RO Water, 5 gm - Preservative Now heat this entire mixture. Heat it well until steam appears; this ensures the water phase is perfectly prepared.**

**STEP 2 - Melt the Oil Phase. Now prepare the Oil Phase in a clean stainless steel vessel. Add: 1kg Mineral Oil, 200 gm Paraffin Wax, 100 gm Microcrystalline Wax, 125 gm Emulsifying Wax. Slowly melt all these ingredients over a low flame. Mix until the entire blend becomes a smooth oil. Now add 15gm Boric Acid. Allow it to dissolve completely in the oil. Complete dissolution of Boric Acid is essential, as it provides the cream with its soothing and antiseptic qualities. Once everything is melted and becomes a glass-like oil, turn off the gas. Your Oil Phase is ready.**

**STEP 3 - Emulsification (Making the Cream) Now the most important step. When both phases are equally warm- Slowly add the Water Phase to the Oil Phase and mix at high speed simultaneously. This is where the cream's thickness, stability, and smoothness are determined. When the mixture becomes milky white and starts to thicken, you know the emulsification is perfect. Now let it cool while continuing to mix. We have used a double cooling method, which allows the cream to set quickly and achieve a soft, rich texture.**

**STEP 4 - Adding Perfume. Once the cream is completely cool (very important- perfume evaporates in hot cream), add: 25 gm Borobliss Perfume. Mix well.**

**STEP 5 - Filling + Packaging. Now fill the cream into 25 gm containers. Apply the labels. After 30-60 minutes, the balm will set and become thick and smooth. Once completely cooled, put on the lids. Your Antiseptic Moisturizing Cream is now ready!**

**Order For Raw Material Pack**

**Call / whatsapp Us On : 9109066526**

  /revoteskincarelabs